



Cleaning the terminal fingerprint sensor

To help ensure you maximise the lifetime, functionality and hygiene of your Terminal fingerprint sensor it's important to keep it clean and free from dust, scratches or grease.

Here we provide some simple guidelines to follow

- Disconnect your terminal from the power supply
- Dampen a lint-free cloth (not sponge, tissue or paper) with approx 1-2ml of ethanol to 75% concentration
- Do not wipe but gently dab the cloth on all of the fingerprint sensor surface
- Repeat until the sensor is evenly clean with no remaining spots or drops
- Wait until the sensor is dry and free of any stains, smudges or residue.
- Now re-connect to the power supply

- DO NOT pour or spray any liquid directly onto or near the sensor**
- DO NOT use paper, rough, abrasive or corrosive material on the sensor**

If you have any further questions please don't hesitate to contact us at support.time@brightecgroup.com